Building & Grounds List May

- 1. Each year the church has to submit water samples to either the State of Illinois or McHenry County. Sample taking bottles will be mailed to the church each spring for this purpose. There is a three-ring binder on a shelf in the key closet that contains detailed instructions. Follow the instructions and send the water samples to the appropriate testing authority.
- 2. Reset light timers throughout building to come on about 30 minutes before it gets dark and off at dawn.
 - a. By old front door
 - b. In janitors closet
 - c. In mechanical room across from choir room
 - d. In far corner closet, next to electrical panel, in Fellowship Hall
- 3. Change all thermostats from Heat to Cool press system button to change.
- 4. Clean Air Filters and lens in Power Point projectors on Sanctuary ceiling. You may need help setting up scaffolding to reach projectors. A vacuum works best to clean filters.

Rear - Sanyo Projector PLC-XT16

AIR FILTER CARE AND CLEANING

Removable Air Filters prevents dust from accumulating on the surface of Projection Lens and Projection Mirror. Should Air Filters become clogged with dust particles, it will reduce Cooling Fans' effectiveness and may result in internal heat build up and adversely affect the life of the projector. Clean Air Filters following the steps below:

- 1 Turn off the projector, and disconnect AC power cord from the AC outlet.
- 2 Turn the projector upside down and remove four Air Filters by pulling the latches upward.
- Clean Air Filters with a brush or wash out dust and particles.
- 4 Replace four Air Filters properly. Make sure that Air Filters are fully inserted.




CAUTION

Do not operate the projector with Air Filter removed. Dust may accumulate on LCD Panel and Projection Mirror degrading picture quality.

Do not put small parts into Air Intake Vents. It may result in malfunction of the projector.


AIR FILTER
Pull up and remove



Front – Sanyo Projector PLC-XU106

Cleaning the Filter

- 1. The 2 filters are on top of the projector.
- 2. Remove the filters by pulling the latches upward.
- 3. Gently clean the filters by using a brush or rinse them softly.
- 4. When rinsing the filters, dry them well. Replace the filters properly. Make sure that the filters are fully inserted to the projector.
- 5. Clean lens and check focus and aim of projector before removing scaffolding.



Pull up and remove.

√Note:

When reinserting these filters, be sure that the slit part is facing the outer side.

Resetting the filter counter

On remote control press MENU, select SETTING, select FILTER COUNTER, select FILTER COUNTER RESET, YES, YES